

SHARP TOP CHAIN INSTALLATION AND MAINTENANCE

Sprocket alignment procedures, tensioning guidelines, and wear monitoring best practices for sharp top conveyor chains.

INSTALLATION & MAINTENANCE GUIDE

1. Pre-Installation Inspection

- ☐ Verify chain pitch matches sprocket pitch
- ☐ Inspect sprocket teeth for wear — replace if hooked or pointed
- ☐ Check that wear strips are flat and properly spaced
- ☐ Ensure conveyor frame is level and aligned
- ☐ Confirm chain width matches wear strip spacing
- ☐ Inspect all connecting links and pins for damage

2. Sprocket Alignment

Proper sprocket alignment is critical for sharp top chains. Misaligned sprockets cause uneven tooth wear, premature elongation, and potential chain derailment.

Alignment Procedure

1. Mount drive sprocket on shaft — tighten set screws to specified torque
2. Mount idler/tail sprocket — hand tighten only at this stage
3. Stretch a taut string across the face of both sprockets
4. Adjust idler sprocket until string contacts both sprocket faces evenly
5. Check angular alignment — string should contact top and bottom of teeth equally
6. Torque idler sprocket set screws to specification
7. Re-check alignment after torque application

CRITICAL

Sharp top chains are direction-sensitive. Teeth must point in the direction of product travel. Installing a chain backwards will cause product slippage and accelerated tooth wear.

3. Chain Tensioning

Horizontal conveyors	1%-2% of span – slight sag visible at midpoint
Incline conveyors (up to 15°)	0.5%-1% of span – minimal sag

Steep incline (15°+)	Near-taut – chain should not sag under load
Decline conveyors	2%-3% of span – more sag to prevent back-tension

Tensioning Procedure

- 1. Install chain around both sprockets
- 2. Adjust take-up (tensioner) until chain is snug but not taut
- 3. Rotate the drive sprocket one full revolution by hand
- 4. Check for binding, tight spots, or sprocket tooth interference
- 5. Set final tension per the table above
- 6. Lock take-up in position

4. Wear Monitoring

Key Wear Indicators

INDICATOR	MEASUREMENT METHOD	ACTION THRESHOLD
Chain elongation	Measure 10 pitches, compare to new	Replace at 2% elongation
Tooth height reduction	Measure tooth height vs. original spec	Replace at 30% wear
Sprocket tooth hook	Visual inspection for hooked teeth	Replace sprocket immediately
Pin wear	Measure pin diameter at wear point	Replace at 5% diameter reduction
Plate wear	Measure plate thickness at contact area	Replace at 10% thickness loss

5. Preventative Maintenance Schedule

FREQUENCY	TASK
Daily	Visual inspection for debris buildup, unusual noise, or mis-tracking
Weekly	Check chain tension, clean tooth surfaces, inspect for broken teeth
Monthly	Measure chain elongation, inspect sprocket teeth, check take-up travel remaining
Quarterly	Lubricate pins (if applicable), inspect wear strips, check drive alignment
Annually	Complete chain measurement, sprocket inspection, take-up replacement if maxed out

6. Common Issues & Solutions

ISSUE	LIKELY CAUSE	SOLUTION
Product slippage	Worn teeth, wrong direction, or insufficient tension	Check tooth direction, replace worn chain, increase tension
Uneven tooth wear	Sprocket misalignment or shaft deflection	Re-align sprockets, check shaft straightness

Chain jump-off	Worn sprockets, excessive slack, debris	Replace sprockets, adjust tension, clean sprocket pockets
Excessive noise	Lack of lubrication, worn pins, sprocket wear	Lubricate, inspect pin wear, replace sprockets if hooked
Premature elongation	Overload, abrasive environment, inadequate lubrication	Verify load rating, install scraper/cleaner, establish lube schedule

MAINTENANCE QUESTIONS?

Uniking Canada provides technical support and replacement parts for all sharp top chain systems.

info@unikingcanada.com

